

CD10002D - CDI Peugeot Speedfight 1



FITTING INSTRUCTIONS

This unit is compatible with original Magneti Marelli CDI marked AEC400

- Step 1 Bolt unit in original CDI position
- Step 2 Unplug 3 way connections on bike and connect by-pass on CD10002D.
- Step 3 Connect black with M6 ring terminal to good earth.
- Step 4 Connect orange terminal block in the original connector block (which fitted in original CDI). This is to make connection to HT coil easier, rather than removing extra panels to allow access to HT coil.
- Step 5 Connect black/red to original black/red from stator source coil.
- Step 6 Other black/red is engine stop, connect to black/red from kill switch (if this is earthed there is no ignition).

