

C12 Ignition Coil



Kawasaki KX80 1981-91, KX100/125 1989-91



FITTING INSTRUCTIONS

READ THESE INSTRUCTIONS CAREFULLY

- Step 1** Take the ignition cover off. Check the new parts are similar to the old ones and that they match, including the mounting hole locations. If not, double check the application listing with your bike.
- Step 2** Make a note of the cable colours from the original stator and disconnect them from the wiring loom.
- Step 3** Remove the flywheel using a proper puller tool and remove the base-plate with the original stator.
- Step 4** Remove the screws that secure the ignition coil and take the coil off.
- Step 5** Cut the original cables close to the original coil. Make a note of which cable colour goes to which side of the original coil.
- Step 6** Mount the coil onto the base plate, fit the screws using locking compound on the threads and **tighten securely!**
- Step 7** Connect the old cables to the new coil (see connections below) in exactly the same place as on the original, making sure you have good connections. Crimp or solder connections as appropriate. When crimping the connections use high quality crimps. If soldering use a resin core solder (the type used in electrical applications) but be aware that solder doesn't always work very well on older wires. If appropriate insulate the wire connections with a heat shrinking sleeve.
- Step 8** Refit the stator base plate. Ensure the cables **cannot touch the flywheel** (especially on the inside of the flywheel).
- Step 9** Refit the flywheel. Tighten the bolt to specified torque.
- Step 10** Connect the cables to the wiring loom on the bike.
- Step 11** Fit the ignition cover.



CONNECTIONS	
Existing wiring	On C12 connect to
RED	RED
BLACK/RED	BLACK

TROUBLESHOOTING

Engine will not start: You may have connected the source coil cables in the wrong position. Swap the connections, re-solder the cables and the engine should start.

If the engine still does not start: Re-check the connections. Make sure you carefully crimp or solder the connections. Twisting cables together or taping cables may cause a poor spark or no spark at all.

If you still cannot get the engine to start, have all your testing